

Electricity theory



G.Schay

Electrostatics: charges in resting state (not moving)



Discovery:


Thales of Milet (624BC-546BC)

Rubbed amber can attract fur/feather



"electron" was the name of amber in greek ☺

Experiments:
When we rub materials then they accumulate "charge" and attract or repel each other.
(triboelectric effect)




Triboelectric series:
Most positively charged
+
Polyurethane foam
Hair, dry skin
Nylon, dry skin
Glass
Acrylic, Lucite
Lantern
Rubber's fur
Quartz
Mica
Lard
Cat's fur
Silk
Aluminium
Paper (small positive charge)
Cotton
Wood (like charge)
0
Wood (like charge)
Wood (small negative charge)
Amber
Sealing wax
Polyethylene
Rubber balloon
Resin
Hard rubber
Nickel, Copper
Sulfur
Starch, Silver
Gold, Platinum
Austrian, Soap
Synthetic rubber
Polyester
Styrene and polystyrene
Glass
Plastic wrap
Polyethylene (like Scotch tape)
Polypropylene
Vinyl (PVC)
Silicon
Teflon (PTFE)
Silicone rubber
Ebonite
-
Most negatively charged

Here we need **vectors**, since everything has **direction + size**


Force: something which describes an interaction.

VECTOR: has size AND direction.

Vectoralgebra: calculation rules with vectors:




The algebra makes it possible to **break up** vectors, just like numbers.
 Az algebra lehetőséget ad a vektorok FELBONTÁSÁRA is!
 (10=3+7 or 10=4+6 or 10=5.01 + 4.99, etc)



We have endless possibilities, with size and direction being free.

We always choose the breakup which makes our life easy ☺

Usually we use two INDEPENDENT directions, so we can focus on the directions one by one.



Everything we calculate using vectors enables a breakup.





The electroscope

As the two rods (the base and the rotating) are charged equally, they repel each other. This enables the rotatable bar to increase the distance to the base rod.

First quantitative measurements:

Coulomb's Force





There exists a minimum charge

$$e = 1.6 \cdot 10^{-19} \text{ C}$$

There is no charge on it's own, it is always carried by some material

The modern way of defining the constant:

$$k_e = \frac{1}{4\pi\epsilon_0} = \frac{c^2}{10^7} = \frac{1}{9 \cdot 10^9} \text{ N} \cdot \text{m}^2 \cdot \text{C}^{-2}$$

$$= 8.987551787364 \cdot 10^9 \text{ N} \cdot \text{m}^2 \cdot \text{C}^{-2}$$

What transmits the force?

Electrical **field**

Force field: a type of vector, which is present in all points in space, but may depend on the position. The vector is related to the force acting on an object at the same position.


Let's define the **electric field** as the force acting on +1C charged positive testing object **E**



With this $F=q \cdot E$
And $E=k \cdot Q/r^2$

Unit: $[F]/[q] = \text{N/C}$

In a field, we can draw the directions of the force with lines: **field lines**



Rules:

- 1: the direction of the force is parallel to the tangential of the field lines.
- 2: the size of the force is proportional to the density of lines.

Work in an electric field:

$W=F \cdot s$, so here we also have a work if we move parallel to the field lines.

$$F=q \cdot E$$

So

$$W=q \cdot E \cdot s$$

Here it is convenient to have $W=q \cdot \Delta\phi$, and define the electric potential ϕ .
(just like $E_{\text{pot}}=mgh$)

So $\phi = E \cdot s$, BUT we need a 0=point.

Let's define $\phi = 0$ if we are infinitely far away

Now we can say that **the electric potential ϕ is equal to the work needed to move +1C charge from infinity to the given position.**

Since E is a conservative force field (just like gravity) the way is not important, just the start and end positions.

$U = \Delta\phi$, electric voltage. Unit: $[W]/[q] = \text{J/C} = \text{Volt [V]}$.

So we have **$W=q \cdot U$**

We have now **field lines** and **equipotential lines**


Notice that they are always perpendicular!
($\Delta\phi = 0$ if $F \cdot \Delta s = 0 \rightarrow \cos\alpha = 0$, so $\alpha = 90$ deg.)




We can make geometrical constructs of charges...

Dipole

Dipole moment: $p = q \cdot d$



Quadrupole...



All kinds of charge distributions
can be modelled by a series of
geometrical objects together.
(multipole expansion)


Storing charges: the capacitor

We need work to move the charge into
the capacitor.
(like charges repel each other...)

The CAPACITY (C) is a measure of the
storing capability of the device: $Q = C \cdot U$, or

$$C = Q/U$$

Unit: $C/V = F$ (Farad)




Leyden jar

Simplest case for calculation:
Flat panel capacitor

Here the E is constant, homogeneous field.
So $U = E \cdot d$
But
 $E = \sigma / \epsilon_0$, where σ is the charge density ($\sigma = Q/A$)
And ϵ_0 is the vacuum permittivity (see later)

With this $C = Q/U = Q / (Q/A \cdot 1/\epsilon_0 \cdot d) = \epsilon_0 \cdot A/d$

If we have some material in the gap then:
 $C = \epsilon_0 \epsilon_r \cdot A/d$
Where ϵ_r is the permittivity of the material.



Electric field in materials:

The electric field creates (induces) dipoles in a material, which has its own field. This adds up to the original, so we get a modified field.

$$D = P + \epsilon_0 \cdot E$$

Where D is the electric displacement vector, and P is the polarization.
(P is the dipole moment of a volume element in the material)

Usually $P = \chi \cdot \epsilon_0 \cdot E$, so
 $D = \epsilon_r \cdot \epsilon_0 \cdot E$

If we have no material, just classical vacuum then $D = \epsilon_0 \cdot E$.

Permittivity: how much charge is needed to generate a given flux.
(flux measures the electric field going through a surface)


Circuits of capacitors:

Parallel: more surface, more capacity

$$C_{\text{tot}} = C_1 + C_2$$

Series: more distance, less capacity

$$1/C_{\text{tot}} = 1/C_1 + 1/C_2$$



We can calculate the work needed to charge up a capacitor


$$\Delta W = U \cdot \Delta q$$

But

$$C = Q/U, \text{ so the slope is } 1/C \text{ here.}$$

The total work is
 $U_{\text{average}} \cdot Q$, but $U = Q/C$

Which is
 $\frac{1}{2} Q^2/C = \frac{1}{2} C U^2$



Moving charges

Some calculation problems:

A Cl^- -ion and a Na^+ -ion are exactly on the opposite sides of a cell membrane. By what force do they attract one other if the thickness of the membrane is 6 nm?

The membrane potential measured between the two sides of an excitable cell is -90 mV. Suppose that the electric field in the 10 nm thick membrane is homogeneous. Find the field strength.

A capacitor of 50 nF capacitance has a charge of $30 \mu\text{C}$. Determine

- the voltage of the capacitor and
- the energy stored in the capacitor.


We measure how much charge flows in a given time

$$I = \frac{\Delta Q}{\Delta t} \quad [A] \quad A = \frac{C}{s}$$

The traditional direction is for the POSITIVE charge, Which is the lack of electrons.

So the real flow is always opposite to the "technical" direction!

What can move is the electrons.
(If there are free, movable electrons in a **conductor**
If not then it is an **insulator**.)




Resistors

When electrons move in materials they hit the atoms and loose speed. Just like friction!

Ohm's law: the flow is determined by the voltage and the material:

$$I = U/R$$




Conductance / conductivity: the inverse of the ohmic resistivity

$$G = 1/R : \text{conductance (1/Ohm = Siemens)}$$


$$\sigma = 1/\rho : \text{conductivity}$$

We usually use this for electrolytes, etc.
(σ is proportional to the concentration)




The movement can be unidirectional or changing:

DC: direct current



AC: alternating current

Here the +/- indicates a reversed direction



$$I = I_{\max} \cdot \sin(\omega t)$$

$$U = U_{\max} \cdot \sin(\omega t + \varphi)$$

$$I_{\text{eff}} = \frac{I_{\max}}{\sqrt{2}} \quad U_{\text{eff}} = \frac{U_{\max}}{\sqrt{2}}$$

I_{rms}

U_{rms}


Circuits of resistors:

Series: more length => more R

$$R = R_1 + R_2$$

Parallel: more space to go => less R

$$1/R = 1/R_1 + 1/R_2$$



More ways to go,
more area for the flow

Heat of the friction: Joule's work / Joule's heat

$$W = U \cdot I \cdot t. \text{ Unit: joule (J)}$$

It is general: the work done by the electric field to move the charges is transformed into heat if the current flows through a resistor.

BUT


The electrical field can do other types of work too (electric motors, LED, etc).

Do not forget the energy conservation law!


$$\text{Power: } P = U \cdot I, \text{ unit: Watt (W)}$$

Kirchoff's laws


- I. Junction law: the sum of currents must match the storage in the junction. If there is no storage, then the sum is 0 (taking direction into account by +/-)



- II. Loop law: in a closed loop the sum of electrical potential changes is 0. Here we have to take the +/- again into account, and use a single direction for the loop.



RC circuit



Discharge a capacitor through a resistor


 $C = Q/U_C$, so $U_C = Q/C$, but $Q = I \cdot t$, and $I = U_C/R$.

 What we get for the loop eq. is:
 $I \cdot R + U_C = 0$

$$\Delta Q / \Delta t = -Q/RC$$

$$\tau = RC$$

$$U_C = U_0 \cdot e^{-\frac{t}{RC}}$$




Charging up:

Here the loop equation includes the battery:


$$I \cdot R + U_C = U_T$$

So

$$\Delta Q / \Delta t = -Q/RC + U_T/R$$



$$U_C = U_T \cdot (1 - e^{-\frac{t}{RC}})$$




Capacitor in a circuit

After charging/discharging in a DC circuit it is like a break.


 In an AC it is periodically charged/discharged
 So it acts as a resistor-like object,
 BUT it is in a different phase than pure
 resistors, here **there is a phase shift!**

Capacitive reactance

$$X_C = \frac{1}{\omega C}$$

 More capacity, less reactance
 higher freq, less reactance

Extension material: since the phase shift causes a shift between I and U , the AC resistance or IMPEDANCE can not be calculated so easily, but if we let the reactance behave like a vector then it is straightforward.

EXT



EXT

